INFORMATION

Note that the functions described in this PDF may not be available, depending on the firmware version of your transceiver.

If you cannot find the setting items on the menu screen, contact your dealer for support.

ABOUT THE MMSI CODE

MMSI (Maritime Mobile Service Identity) is the 9-digit number assigned to your vessel or coast station by your country's relevant authority, which is necessary for using DSC (Digital Selective Calling), AIS (Automatic Identification System), and distress alerts.

To use DSC, AIS, and distress alerts, the MMSI code must be obtained and entered.

■ Obtaining the MMSI code

For users in the USA:

To obtain the MMSI code, access the website from the following QR code.

ⓘ Icom cannot issue MMSI codes.

ⓘ If you cannot access the website using the QR code, please access the page below.
https://www.uscg.mil/

For users in other countries or regions:

Check your local regulations for details on obtaining the MMSI code.

■ Entering the MMSI code

For users in the USA:

It is a violation of the rules of the Federal Communications Commission to input an MMSI that has not been properly assigned to the end user, or to otherwise input any inaccurate data in this device.

For users in other countries or regions:

Check your local regulations for details on entering the MMSI code.

ⓘ Refer to the PREPARATIONS section of your transceiver's manual on how to enter an MMSI code.

For information on resetting the MMSI code, please refer to pages 2 and 3.

■ When changing the MMSI code

This section is only for users who need to clear the MMSI code entered into the transceiver for any reason, such as incorrectly entering the MMSI code.

◇ To request the Activation code

Contact Icom by e-mail with the following information.
(E-mail address: MMSI-reset-request@icom.co.jp)

ⓘ This E-mail address is only for requesting an Activation code, not for requesting an MMSI code. Icom cannot issue MMSI codes.

Please be aware that we may ask you to provide proof of purchase when you request an MMSI reset activation code due to certain situations.

Required information:

- Model name
- Request code (16 digit number)
  ⓘ See below how to check the Request code on your transceiver.

Checking your Request code:

You can check the Request code on your transceiver's menu screen.

1. Open the "MMSI Clear" screen.
   [Menu] > Configuration > **MMSI Clear**



   ⓘ The "MMSI Clear" menu is displayed only when the MMSI code or the ATIS ID has been set.

2. Select "Request Code," and then push [ENT].
   • A 16 digit of Request code is displayed.




   ⓘ The code above is only an example.

◇ Reprogramming the MMSI code


After Icom accepts your request, you will be sent an Activation code for the reset operation. Enter the Activation code to your transceiver and reset the MMSI code.

CAUTION:
- The Activation code can be used only once.
- For transceivers programmed with ATIS, the reset operation clears both the MMSI code and the ATIS ID.

1. Open the "MMSI Clear" screen.
   [Menu] > Configuration > **MMSI Clear**
2. Select "Activate," and then push [ENT].



3. Enter the 16 digit of Activation code.




   ⓘ The code above is only an example.

TIP:
- Select a number using [◄] and [►].
- Push [ENT] to enter the selected number.
- Select "←" or "→" on the screen or rotate [DIAL] to move the cursor.

4. Push **FIN** to set the entered code.
   • When the Activation code is successfully entered, the following screen is displayed.



   ⓘ If the entered code is not correct, an error message is displayed, and then returns to the input screen. Enter the correct Activation code.



5. Push **OK** to clear the MMSI code and ATIS ID.
   • The transceiver restarts.

NOTE: Refer to the PREPARATIONS section of your transceiver's manual on how to enter your new MMSI code and ATIS ID.